

Crupi Gear Ratios

20 x 1.75 (19.50" inflated diameter)																			
Gear		34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
Free Wheel	9																		
	10	66.3	68.3	70.2															
	11	60.3	62.0	63.8	65.6	67.4	69.1	70.9											
	12	55.3	56.9	58.5	60.1	61.8	63.4	65.0	66.6	68.3	69.9	71.5	73.1						
	13	51.0	52.5	54.0	55.5	57.0	58.5	60.0	61.5	63.0	64.5	66.0	67.5	69.0	70.5	72.0			
	14	47.4	48.8	50.1	51.5	52.9	54.3	55.7	57.1	58.5	59.9	61.3	62.7	64.1	65.5	66.9	68.3	69.6	71.0
	15	44.2	45.5	46.8	48.1	49.4	50.7	52.0	53.3	54.6	55.9	57.2	58.5	59.8	61.1	62.4	63.7	65.0	66.3
	16	41.4	42.7	43.9	45.1	46.3	47.5	48.8	50.0	51.2	52.4	53.6	54.8	56.1	57.3	58.5	59.7	60.9	62.2
	17		40.1	41.3	42.4	43.6	44.7	45.9	47.0	48.2	49.3	50.5	51.6	52.8	53.9	55.1	56.2	57.4	58.5
	18			39.0	40.1	41.2	42.3	43.3	44.4	45.5	46.6	47.7	48.8	49.8	50.9	52.0	53.1	54.2	55.3
20							39.0	40.0	41.0	41.9	42.9	43.9	44.9	45.8	46.8	47.8	48.8	49.7	

Front gear size divided by the Freewheel size times the inflated tire diameter equals the gear ratio